

PESA Switching Systems 330A Wynn Drive Huntsville, AL 35805

Document No. 81-9059-0307-0 Rev. E

Manual Updates:

- 06/17/94 Rev. A: Manual released for initial printing.
- 02-28-01 Rev. B: Not released Agile conversion. GLT
- 02-28-01 Rev. C: Synchronized revision level with Agile per ECO CE00126. GLT
- 03-02-01 Rev. D: Deleted Printing Specification per ECO CE00113. GLT
- 03-16-01 Rev. E: Deleted bills of material, drawings, and schematice per ECO CE00130. GLT

Ordering Assistance, Service & Inquiries

Service and Ordering Assistance

PESA Switching Systems, Inc. 330A Wynn Drive Huntsville, AL 35805 Main Numbers: Tel: (256) 726-9200 Fax: (256) 726-9271 Service Department Numbers: Tel: (256) 726-9222 Fax: (256) 726-9268

Sales Office

National Sales Office PESA Switching Systems, Inc. 35 Pinelawn Road, Suite 99E Melville, NY 11747 Tel: (800) 328-1008 Fax: (516) 845-5023



NOTE

PESA reserves the right to change any information contained in this manual without notice. Unauthorized copying, modifications, distribution, or display is prohibited. All rights reserved.

Please address all comments or suggestions concerning this or other PESA manuals to:

Publications Department PESA Switching Systems, Inc. 330A Wynn Drive Huntsville, Alabama 35805 (256) 726-9200 EXT. 145



RCP-48X Control Panel

Section 1. INTRODUCTION

1.1	Manual Overview
1.2	General Description 1.2
	Figure 1-1 RCP-48X Front and Rear Views 1.2
1.3	System Specifications 1.3

Section 2. INSTALLATION

2.1	Introduction	2.1
2.2	Receipt Inspection	2.1
2.3	Location and Mounting	2.1
	Figure 2-1 RCP-48X Chassis Installation	2.2
2.4	Polling Address	2.2
	Figure 2-2 DIP Switch Location	2.3
2.5	Control Panel/Controller Interconnection	2.3
	Figure 2-3 Typical Control Panel Interconnection	2.3
2.6	Wiring the Control Panel Connector	2.4
	Figure 2-4 Wiring the Control Panel Connector	
2.7	Terminating Cable Runs	2.5
	Figure 2-5 Terminating Cable Runs	2.5
2.8	Power Connections	2.6
	Figure 2-6 Typical Panel Power Supply	

Section 3. OPERATION

3.1	Operations	3.1
	Introduction	3.1
	General	3.1
	Breakaway Operation	3.2
	Operational Instructions	3.3

RCP-48X Control Panel

Section 4. FUNCTIONAL DESCRIPTION

4.1	IntroductionI	4.1
4.2	CPU Board	4.1
	Power Supply	4.1
	Microprocessor	4.1
	Figure 4–1 Idealized Bus Cycle Timing Diagram	4.2
	Clock	4.2
	Reset	4.3
	Memory	4.3
	LED Driver Support	4.3
	RS-485 Communications	4.4
	I/O	4.4
	Table 4–1 Decoder Addressing	4.5
	Miscellaneous	4.5
4.3	Switchcard	4.5
	RCP-48X Switchcard	4.5
	Switchcard ID	4.5
	Keyboard Scan	4.6
	Table 4-2 Keyboard Memory Map	4.6
	LED Driver	4.7
	I/O Board Interface	4.7

Section 5. MAINTENANCE

General	5.1
Preventive Maintenance	5.1
Test Equipment	5.1
Corrective Maintenance	5.1
Factory Repair Service	5.2
Adjustment/Alignment	5.2
Troubleshooting	5.2
	General Preventive Maintenance Test Equipment Corrective Maintenance Factory Repair Service Adjustment/Alignment Troubleshooting

1.1 Manual Overview

This manual provides detailed instructions for installing and operating the PESA RCP-48X. This manual is divided into five sections as shown.



Section 1, **INTRODUCTION**, summarizes the manual, describes the RCP-48X, presents a list of terms, and provides the panel specifications.



Section 2, **INSTALLATION**, provides installation and setup instructions.



Section 3, **OPERATION**, describes operation procedures.



Section 4, **FUNCTIONAL DESCRIPTIONS**, presents an indepth description of each RCP-48X component.



Section 5, **MAINTENANCE**, explains procedures for maintenance.



1.2 General Description

The RCP-48X is designed to provide an economical solution for installations requiring fast, intuitive operation. It is a button-per-source or destination panel featuring direct take operation for up to 16 levels of control of a router destination. This panel is recommended for applications requiring minimum keystrokes and a limited number of sources for a limited number destinations. The RCP-48X can access one or more router destinations.

There are two control pushbuttons on the right. One allows the operator to Protect or Lock the assigned destination while the other allows the operator to select an individual Level(s) to be controlled or display the panel address.

This panel comes packaged in a standard 19 inch, one rack unit (1RU) chassis requiring only 1 1/2 inches of depth, making it suitable for tight locations. The unit is powered by a 7.5VDC Plug-in-the-Wall type power pack and communicates with the System Controller via a Standard RS485 Interface.

\bigcirc "		" ()
-	DECA	Prot
	PESA	Level Addr
\Box_{n}		

0
0~

Figure 1-1 RCP-48X Front and Rear Views



RCP-48X

Introduction

1.3 Specifications

GENERAL Mounting

Pushbuttons

Standard 19" Rack

LED Illuminated

INPUT Input Type

RS485

POWER Voltage Requirements

+7.5 VDC @ 800 mA

MECHANICAL

One Rack Unit

ENVIRONMENTAL Temperature Humidity 19"W x 1 1/2"D x 1 3/4"H (482.6mmx38.1mmx44.45mm)

0°C to 40°C 20% to 90% Non-Condensing





2.1 Introduction

This section details RCP-48X installation procedures. The following topics are discussed:

- Receipt Inspection
- Location and Mounting
- Polling Address
- Control Panel/Controller Interconnection
- Power connections

2.2 Receipt Inspection

The RCP-48X was inspected and tested prior to leaving the PESA factory. Upon receipt, please inspect the unit for shipping damage. If damage is detected, notify the carrier immediately and hold all packing material for inspection. If assistance is required, please contact PESA Customer Service at the telephone number listed in the front of this manual.

After unpacking, compare all parts received against the packing list. If the unit is undamaged and all components have been received, proceed with installation.

2.3 Location and Mounting

The RCP-48X has been designed to fit in a standard E.I.A. 19" equipment rack and uses 1 rack unit of space (1 3/4"). An area should be selected where temperature does not exceed 40°C inside the equipment rack, and where air can circulate freely. The unit should be mounted in an area convenient to control and power connections. Sufficient space must be provided behind the rack to allow for the control and power cables. All mounting holes should be utilized and hardware tightened securely. All cables should be strained relieved and secured to racks or other supporting structures. Failure to provide adequate cable support can result in cables separating from connectors. If cable runs are to be stored under an elevated floor, they should be tied to the racks as a guide. If cables are run along the floor, do not allow them to lay in the work area behind the racks. Stepping or tripping on the cables may result in connections being pulled free or wire breakage inside the insulation.



Location and Mounting Continued:

Figure 2-1 illustrates chassis installation.

To install the RCP-48X chassis follow these steps:

- 1. Align the chassis with the slotted opening in the rack.
- 2. Install the bottom screws first.
- 3. Install the two top screws
- 4. Tighten all four screws securely.



Figure 2-1 RCP-48X Chassis Installation

2.4 Polling Address

For the controller to identify a particular control panel, a specific device number or polling address must be assigned to each panel. Valid polling addresses are in the range of 1 to 128. Systems requiring more than 128 panels are possible with enhanced controllers, refer to your Pesa Sales Representative for details. The appropriate binary number is entered into the control panel by setting a 10-position DIP switch to the binary number. The DIP switch is located on the remote CPU board and is accessible from the rear of the unit. The panel address is normally assigned and entered at the factory if the panel is purchased as part of a system and a design guide has been completed by the user. If the panel is purchased separately, the user may be required to set the panel address.

Example: To select polling address 21, set switches 6, 8, and 10 in the "ON" or "1" position. See Figure 2–2.



2.4 Polling Address (Device Number) Continued:



Figure 2-2 DIP Switch Location

2.5 Control Panel/Controller Interconnection

Each panel has a single 3-pin MTA connector located on the rear panel. Control panels are daisy chained to a port on the rear of the Controller. Use shielded twisted pair cable. See Figure 2-3.







2.6 Wiring the Control Panel Connector

Should an additional control panel be added to your system, it will be necessary to wire the connector using shielded twisted pair cable and a 3pin MTA connector. See Figure 2-4.

- 1. Remove approximately 1 1/2" of insulating jacket from each of the two wires.
- 2. Remove approximately 1/2" of wire insulation from the black and red wires.
- 3. Twist together and insert the two black wire ends into positon 1. Crimp down using a screw driver.
- 4. Twist together and insert the two shield wires into position 2. Crimp down using a screwdriver.
- 5. Twist together and insert the two red wire ends into position 3. Crimp down using a screwdriver.







2.7 Terminating Cable Runs

Each cable run should be terminated at the end of the run with a 120ý, 1/4 watt 5% resistor. The cable is terminated internally at the controller. See Figure 2-5.

- 1. Uncrimp the black and red leads in position 1 and 3.
- 2. Insert the resistor ends into position 1 and position 3 along with the black and red leads.
- 3. Crimp down using a screwdriver.
- 4. The shield wire remains in position 2.







2.8 Power Connections

Power for the RCP-48X is supplied by an external 7.5 Vdc, 800 mA power supply.

Remove the Power Supply from the box it was shipped in and check to insure that no damage has occurred in shipping. Verify that the Power Supply is rated for the proper AC voltage (i.e. 115 VAC or 230 VAC) before connection to the AC voltage. The power connector can now be plugged into the **POWER IN** position on the RCP-48X. The Power Pack will immediately power the unit upon connections to AC Voltage. See Figure 2-6.



Figure 2-6 Typical Panel Power Supply



3.1 Operations of the RCP-48X

Introduction

The RCP-48X is controlled by the RC5500 Controller. Operations of the RCP-48X require that it be configured at the controller and have the appropriate polling address assigned. Connections and power up procedures should be performed on each panel controlled.

General

All RCP-48X panels in a routing switcher system are custom configured at the factory prior to shipment. The information needed to configure the panels comes from the System Design Guide filled out by the customer.



Breakaway Operation

Breakaway operation allows you to select an input to be switched to an output on one or more specific levels. **Assumptions:** Panel is currently in Direct Take mode (default mode) and no level has been selected for breakaway (Level/Disp. LED is not illuminated or blinking).

To Make a Breakaway Switch: Depress Level/Address Key	Results: Level/Address Key lights. Panel enters Level Select Mode. Data Keys represent Levels.
Depress Data Key associated with level(s) you wish to breakaway	Data Key(s) selected light to show level selection(s).
Depress Level/Address Key again	Level/Address key blinks. Panel returns to Direct Take Mode but with Level(s) selected for breakaway. Data Key whose associated input matches the current status on the selected level(s) will be illuminated.
Depress the Data Key associated with the input you desire on the level(s) selected	The destination controlled by the panel will be switched to the input assigned to the Data Key pressed for each level selected.
To Return to Follow Operation: Depress the Level/Address Key again	Results: Level/Address Key lights. Panel enters Level Select Mode again. Data Keys associated with currently selected level(s) light.
Depress Data Key(s) currently lit	Data Key LEDs are extinguished and associated levels are no longer selected for breakaway operation.
Depress Level/Address Key again	Level/Address Key LED is extinguished Panel returns to Direct Take Mode but with no levels broken away (Follow operation). Data Key whose source matches the current status is illuminated.



RCP-48X	Operations		
	DATA KEYS		

The RCP-48X has 2 Modes of Operation:

Direct Take - Selects sources to be switched to the destination controlled by the panel by depressing associated Data Keys. Switch requests are sent immediately. Direct Take is the default mode; deselecting the Level Select mode will always return you to the Direct Take mode. The Level/ Address Key will not be illuminated if the panel is in Follow or blinking if you have selected Breakaway level(s).

Level Select - Selects which levels are to be affected when selecting switches in Direct Take mode. Enter the Level Select mode by depressing the Level/Address key for less than 2 seconds. The Levels/Address key is illuminated in this mode of operation.

PANEL CONFIGURATION:

Address: Decimal number from 1 to 128 which is used to distinguish each panel on the panel communications bus. Address must match the dip switch setting on the rear of the panel. Systems requiring more than 128 panels are possible with enhanced controllers: refer to your Pesa Sales Representative for details.

Panel Name: Any 8 alphanumeric characters. Currently used only by the controller configuration program to provide a user-friendly method of referring to each panel.

Priority: Choice of 3 priorities: Master, Supervisory, or Non-Supervisory. Priorities are used when panel attempts to set or clear a destination Protect/Lock. Only the panel which set a Protect/Lock, or someone of higher priority can unlock a destination. The default setting is Non-Supervisory.

Status Method: The panel displays status differently based on whether the panel is set for Follow (changing all levels assigned to panel) or Breakaway (changing only selected levels) operation. In addition, you may select between 2 methods of displaying status when in Follow (NOTE: these methods only apply when the panel is set for Follow operation):

Group Status: Panel will display status based on the Source Group which changed the current destination. If the panel receives status due to a Breakaway change request, or due to a change made elsewhere in the system, the panel will display the status of the Default Status Level (refer to the Controller Operations Manual for more details).

Data Keys: 48 Data Keys are located towards the left of the panel. Data Keys are associated with sources or destinations in Direct Take mode and levels in the Level Select mode. The source/destination assigned to each Data Key is configurable from the controller.

Function Keys: Two function keys are located to the far right of the panel: Protect / Lock and Level / Display Address. Each function key works as a toggle; the primary function is listed first, followed by the secondary function. NOTE: The primary function is executed when the key is held down less than 2 seconds. The secondary function is executed when the key is held down more than 2 seconds.

Default Status Level Status: Panel will always display the status of the Default Status Level.

Default Destination Group: Destination group to be controlled by the panel on panel boot-up.

Default Status Level: The level that will be statused when panel is in Follow operation and status is not determined by the Group Status (refer to the preceding Status Method description).

Level List: List of levels to be controlled by the panel. Any level not in the assigned Level List will not be accessible to or affected by panel operations.

Key Assignment List: List containing the assignment of source/destination groups to each of the Data Keys.







STATUSING:

Status by Group Status

LED Illuminated Solid (not blinking) - The current status matches the source(s) assigned to the Data Key.

LED Blinking - The current status matches the source(s) assigned to the Data Key on some, *but not all*, levels.

No LED Illuminated - The current status does not match the source(s) assigned to any Data Key.

Status by Default Status Level

LED Illuminated Solid (not blinking) - The current status matches the source assigned to the Data Key for the default status level and the source(s) assigned to the Data Key for other levels either match the status on the default status level or are not configured.

LED Blinking - The current status matches the source assigned to the Data Key for the default status level and the source(s) assigned to the Data Key for at least one other level does not match the status on the default status level.

No LED Illuminated - The current status does not match the source assigned to any Data Key on the default status level.

Breakaway Statusing

LED Illuminated Solid (not blinking) - The current status matches the source assigned to the Data Key for the highest priority level selected (level 1 is highest priority) and the source(s) assigned to the Data Key for other levels selected either match the current status or are not configured.

LED Blinking - The current status matches the source assigned to the Data Key for the highest priority level selected (level 1 is the highest priority) but the source(s) assigned to the Data Key for at least one other selected level does not match the current status.

No LED Illuminated - The current status does not match the source assigned to any Data Key on the highest priority level selected (level 1 is the highest priority).

NOTE: If the destination group being controlled by the panel matches a Destination Data Key, the Destination Data Key's LED will be illuminated.







DIRECT TAKE MODE

DATA KEYS:

In this mode, Data Keys are associated with sources and destinations. Pressing a Source Data Key will switch the source assigned to the Data Key on all selected levels to the destination controlled by the panel. Pressing a Destination Data Key will change the destination controlled by the panel. The method of statusing used by the panel is determined by configuration at the controller and whether Breakaway levels are currently selected.

PROTECT/LOCK CONTROL KEY:

PROTect – Protects the destination controlled by the panel. Any switch request attempting to affect this destination made at any location other than this panel will be disallowed. Protect/Lock LED illuminates to show the destination controlled by the panel is protected.

LOCK – Locks the destination controlled by the panel. Any switch request attempting to affect this destination will be disallowed. Protect /Lock LED blinks to show the destination controlled by the panel is locked.

When the panel is unlocked, pressing the PROTect/LOCK key quickly will take the panel into PRO-TECT. Pressing the PROTect/LOCK key for > 2 seconds will take the panel into LOCK. When the panel is already protected or locked, pressing the PROTect/LOCK key quickly will clear PROTECT or LOCK.

LEVEL/ADDRESS KEY:

LEVEL – Activates the Level Select mode. Illuminates the Level/Address LED. Displays the currently selected level(s) by lighting the associated Data Key LEDs, with the first Data Key on the top row corresponding to level 1 and proceeding left to right, top to bottom. If no level is selected, no Data Key will be illuminated (refer to the Level Select Mode description).

ADDR ess– Displays the panel address on the top row of Data Key LEDs while key is depressed. The address will be displayed in binary format. The LSB is the right hand Data Key in the top row.

LEVEL SELECT MODE

DATA KEYS:

In this mode, Data Keys are associated with levels, with the top left Data Key corresponding to level 1 and proceeding left to right, top to bottom. If the panel is in Follow (no Breakaway level[s] selected), no Data Key will be illuminated. If a Data Key is illuminated, the corresponding level is selected. Pressing a Data Key will toggle the selection of the corresponding level (if level is controllable by this panel) by either deselecting it if the Data Key was already illuminated or selecting it and illuminating its associated Data Key if not.

PROTECT/LOCK CONTROL KEY:

PROTect – Protects the destination controlled by the panel. Any switch request attempting to affect this destination made at any location other that this panel will be disallowed. Protect/Lock LED is illuminated to show the destination controlled by the panel is protected.

LOCK – Locks the destination controlled by the panel. Any switch request attempting to affect this destination will be disallowed. Protect/Lock LED blinks to show the destination controlled by the panel is locked.

When the panel is unlocked, pressing the PROTect/LOCK key quickly will take the panel into PRO-TECT. Pressing the PROTect/LOCK key for > 2 seconds will take the panel into LOCK. When the panel is already protected or locked, pressing the PROTect/LOCK key quickly will clear PROTECT or LOCK.

LEVEL/ADDRESS KEY:

LEVEL - Deactivates the Level Select mode and returns to Direct Take mode. Turns off the Level/ Address LED and displays the status of the destination controlled by the panel by lighting the associated Data Key's LED (refer to the Direct Take mode description).

ADDRess - Displays the panel address on the top row of Data Key LEDs while key is held down. The address displayed will be a binary representation of the panel address with the MSB=15 and the LSB=24.





4.1 Introduction

The RCP-48X panel consists of two printed circuit boards. The CPU board contains a microprocessor that controls the panel's operation and communicates with the control system. The Switchcard contains pushbuttons and indicators used by the operator to control the routing switcher. The following is a detailed description of each of these boards.

4.2 CPU Board

The CPU board contains all circuitry necessary to communicate with the system controller and to interface to a front panel switchcard. The circuitry on the CPU board may be divided into the following sections: Power Supply, Microprocessor, Clock, Reset, Memory, LED Driver Support, RS-485 Communications, I/O, and Miscellaneous. The following paragraphs explain each section in detail.

Power Supply

The power supply circuit on the CPU board consists of a 7805 +5V regulator and filter capacitors. Unregulated DC voltage (7.5 to 9 Vdc) is supplied by an external power supply via J3. The voltage regulator U7 reduces the voltage to 5.0 Vdc. C10 and C12 provide filtering for the input and output of the regulator, respectively. Bypass capacitors (.1 uF) are scattered about the board to provide power supply bypassing for individual chips. The regulated voltage is available to external board on both J1 and J2, pins 31 and 32. The unregulated voltage is available to external board on both J1 and J2, pins 29 and 30.

Microprocessor

The heart of the CPU board is the Motorola 68HC11 microprocessor (U1). This IC contains the microprocessor and peripheral circuitry used to operate the panel. In addition, the 68HC11 contains a PROM with the software used to operate the panel. The 68HC11 is operated in the expanded multiplexed mode. In this mode port B (U1 pins 35-42) provides the upper address byte (A8-A15). Port C (U1 pins 9-16) provides both the lower address byte (A0-A7) and the data byte (D0-D7). U2 is used to latch the lower address byte. Figure 4–1 shows an idealized timing diagram for external bus cycles.



Microprocessor Continued:

During the first half of the bus cycle, port C presents the lower address byte (A0-A7). This information is latched into U2 on the falling edge of address strobe AS (U1 pin 4 to U2 pin 11) and remains stable until the beginning of the next bus cycle when AS is driven high by the processor. During the last half of the bus cycle port C presents data during write cycles and accepts data from an external device during read cycles.

The address bus (A0..A15), the data bus (D0..D7), AS, R/W, and E clock are available to external boards via J1.



Figure 4-1 Idealized Bus Cycle Timing Diagram

Clock

The master system clock is provided by oscillator U6 pin 8. SYSCLK is available to the processor (U1 pin 7) and to external boards via J2 pin 10. The frequency of SYSCLK is 7.3728 MHz. This value was chosen to provide an appropriate frequency for the baud rate generator inside the 68HC11. The 68HC11 internally divides SYSCLK by four to derive the bus operating frequency. U1 pin 5 is the E clock used to synchronize all external bus cycles. The frequency of the E clock is 1.8432 MHz (SYSCLK/4). The E clock is used to derive control signals on the CPU board and is available to external boards via J1 pin 28.



Reset

As with all microprocessors, the 68HC11 requires initialization during power-up. The 68HC11 requires that the RESET pin (U1 pin 17) be held low for 4064 cycles of E clock (2.2 mS @ 1.8432 MHz E clock). In addition the RESET pin must be held low while VDD is below legal limits to protect internal EEPROM register contents. A Maxim MAX690 chip (U5) performs the reset function for the 68HC11. The MAX690 monitors the supply voltage and asserts RESET (U5 pin 7) whenever VCC falls below 4.5 Vdc. The RESET signal is guaranteed to be asserted for a minimum of 50 mS after VCC rises above 4.75 Vdc. This is more than adequate to meet the 2.2 mS requirement of the 68HC11. The RESET signal is available to external boards via J2 pin 11.

Memory

The CPU board contains 8K of static RAM (U3). The RAM is selected when both CS1 (U3 pin 20) and CS2 (U3 pin 26) are asserted. CS1 is low active and is driven by address bit A15. Whenever A15 is low, CS1 is asserted. This occurs for addresses in the range of 0000h to 7FFFh. CS2 is high active and is asserted when address bit A14 is high and E clock is high (note the AND gate formed by U8 pins 1, 2, and 3 followed by inverter stage U8 pins 4, 5, and 6). CS2 is active for addresses in the range of 4000h to 7FFFh and C000h to FFFFh. U3 is selected when both CS1 and CS2 are asserted. This occurs for addresses in the range of 4000h to 7FFFh. This encloses an address space of 16K. Since U3 is only 8K in length, it is dually mapped at base addresses of 4000h and 6000h. This means that the same location in the RAM may be accessed either at 4000h or at 6000h. The write enable pin WE (U3 pin 27) is driven low during the last half of write cycles by the U8 pin 8. This WE signal is also availably to external boards via J1 pin 25.

LED Driver Support

The 68HC11 processor uses the internal synchronous peripheral interface (SPI) under software control to drive external LED circuitry. LED_DATA is presented as a serial bitstream on U1 pin 23 and is available to external boards via J2 pin 7. LED_CLOCK is presented on U1 pin 24 and is available to external boards via J2 pin 8. External circuitry should accept LED_DATA on the rising edge of LED_CLOCK. To allow multiple LED drivers to be serviced, the CPU board provides four select lines labelled LED_SEL0..LED_SEL3. These low-active signals are presented at U1 pins 30..27 and are available to external boards via J2 pins 1..4. The data stream generated is compatible with that required by National MM5450 LED driver chips.



RS-485 Communications

Communication between the panel and the system controller is accomplished by the 68HC11 internal Serial Communication Interface (SCI). The SCI is an asynchronous receiver/transmitter, sometimes referred to as a UART. The RS-485 standard is used for the electrical interface between panels and the system controller. A 75ALS176 (U4) chip is used to convert between RS-485 and the levels required by the SCI. Transmit data (TXD) is presented by the SCI on U1 pin 21. This signal drives the input to the RS-485 transceiver on U4 pin 4. Data received from the system controller is converted to the appropriate levels by the RS-485 transceiver and presented on U4 pin 1. This received data (RXD) signal is then fed to the SCI receiver at U1 pin 20. Since the RS-485 interface requires the transmitter to be tri-stated when not in use, a third signal is required to enable/ disable the RS-485 transmitter. The processor provides the TX_ENABLE signal under software control at U1 pin 25. This signal is connected to the RS-485 transceiver at U4 pin 3. When TX_ENABLE is asserted (high), U4 drives the RS-485 bus (U4 pins 6 and 7 to J4 pins 1 and 3). When TX ENABLE is negated (low), U4 ceases driving the bus and allows other devices to drive the bus. During reset, the TX_ENABLE signal from the processor is initialized to an input and is not driven to a particular state. A pull-down resistor R2 has been added to ensure that U4 does not drive the RS-485 bus during power-up or other reset conditions. A shield connection is provides for the RS-485 bus on J4 pin 2. The shield is connected to ground through R1.

I/O

Circuitry is included on the CPU board to support I/O expansion via J1 and J2. Decoder U9 provides eight chip select signals SEL0..SEL7 for use by I/O devices. U9 is selected when A14 and A15 are both low and E is high. This occurs during the last half of each external bus cycle addressing in the range of 0000h to 3FFFh. Table 4-1 lists active address range for each select signal. Currently, the CPU board uses two of these eight signals for on-board circuitry. SEL6 is used to select eight bits of the address dip switch S1. When SEL6 is asserted, U10 places the state of signals SWX3..SWX10 on the data bus. If the corresponding switch for each bit is closed, a logic low is presented. If the switch is open, pullup resistor RP1 presents a logic high. SEL7 is used to select the remaining two bits of the address switch and the six bit ID field from an external board. The ID field should be driven by an external board. A logic low is generated by grounding the ID pin. A logic high is generated by leaving the ID pin floating. Pullup resistor RP3 generates the high logic when a pin is floating.



|--|

Table 4-1 Decoder Addressing

Miscellaneous

The CPU board provides some special function signals for use by external boards. R3/R4 provide a contrast adjustment for LCD displays. The CON-TRAST signal is available for use by external boards on J2 pin 13. Likewise, R5 provides a brightness control signal for use by external boards. It is available on J2 pin 14. J2 pin 9 is a signal named DSP_RS. This signal is a register select signal for external LCD displays. The processor interrupt request line IRQ is not currently used, but is available for use by external board on J2 pin 12. The CPU board accepts input from a rotary encoder in the form of two signals named KNOB0 and KNOB1. The CPU software expects quadrature-encoded signals to indicate direction of travel from the rotary encoder. These two signals are present on J2 pins 5 and 6.

4.3 Switchcard

RCP-48X Switchcard

The switchcard for the RCP-48X panel contains circuitry to provide a switchcard ID for the CPU board, scan a keyboard, light the keyboard LEDs, and interface to an optional I/O board. The following is a description of each of these circuits.

Switchcard ID

The RCP-48X switchcard provides a six-bit ID available to be read by the CPU board. This ID is available on J2, pins 23-28. The least significant bit (ID0) is provided by the optional I/O board on J3 pin 5. If the I/O board is not installed, then ID0 is pulled high by a pullup resistor on the CPU board. If the I/O board is installed, then the ID0 pin is grounded. The CPU may use this bit to detect the presence or absence of the I/O board. The



Switchcard Continued:

remainder of the ID bits (ID1-ID5) are either floating or grounded by the switchcard. Floating pins are pulled high by pullup resistors on the CPU board. The CPU may use these bits to detect what switchcard is attached.

Keyboard Scan

The RCP-48X switchcard contains circuitry capable of scanning up to 64 pushbuttons. The scan circuit is arranged as an eight row by eight column array. While the circuitry is capable of serving 64 pushbuttons, the printed circuit board will only accept 50 pushbuttons. To scan the keyboard, the microprocessor on the CPU board performs read cycles that enable SEL1. This occurs for addresses in the range of 800h to FFFh. SEL1 provides a low-active chip select for a 3 to 8 line decoder (U3 pin 5). A second lowactive chip select is provided by address bit A3 at U3 pin 4. The three least significant address bits (A0-A2) are connected to the input of the decoder (U3 pins 1, 2, and 3). One of the eight low-active outputs of the decoder is selected by placing the appropriate address on the input of the decoder. Since partial decoding is used, the keyboard circuitry is mapped to several addresses within the SEL1 address range. The software in the CPU only uses the lowest available addresses to access the keyboard. Table 4-2 contains the addresses used to access each row of the keyboard circuit.

Address	Row	U3 pin #
800h	KB_ROW0	15
801h	KB_ROW1	14
802h	KB_ROW2	13
803h	KB_ROW3	12
804h	KB_ROW4	11
805h	KB_ROW5	10
806h	KB_ROW6	9
807h	KB_ROW7	7

Table 4-2	Kevboard	Memory	Map
	itey bound	wichiory	map

The CPU scans all eight rows of the keyboard. Each row of pushbuttons contains up to eight individual switches. Example: KB_ROW0 will simultaneously enable pushbuttons S1-S8. If any of these switches is pressed, the low-active signal will be passed through the pushbutton contacts to one of the eight column signals (KB_COL0-KB_COL7). If the pushbutton is not pressed, the switch contacts are broken and the column signal will be pulled high by resistor pack RP1. The SEL1 signal also enables U4 to place the KB_COL signals on the data bus. Thus, by performing a read



Switchcard Continued:

cycle at address 800h, the CPU can determine the state of pushbuttons S1-S8 by looking at the state of data bits D0-D7. If S1 is pressed, then D0 will be low. Likewise, if S2 is pressed, D1 will be low. The status of the entire keyboard array may be determined by performing successive reads of each row of the array.

LED Driver

The RCP-48X switchcard contains circuitry capable of lighting up to 68 LEDs. The RCP-48X uses only 50 of these LEDs, one per pushbutton. The drive for each LED is provided by U1or U2. The CPU sends a serial data stream to U1 and U2 by using the LED_DATA (pin 25) and LED_CLOCK (pin 24) signals. LED_SEL0 (U1 pin 26) must be asserted (low active) to update LEDs 1-34. Likewise, LED_SEL1 (U2 pin 26) must be asserted to update LEDs 35-50. The output current used to drive each LED is enabled by the brightness pin of the LED driver (pin 21). The LED_DATA line is latched into U1 and U2 on the rising edge of LED_CLOCK while LED_SEL0 or LED_SEL1 is asserted.

I/O Board Interface

Connector J3 provides the signals necessary to interface to an optional I/O board. The connector provides +5 Vdc (pin 1) and ground (pin 6) to power the external board. In addition, data bit D0 (pin 2), address bit A0 (pin 3), and chip select SEL5 (pin 4) are present on the connector. Pin 5 of the connector is connected to ID0, and is used to detect the presence or absence of the external board (see Switchcard ID, above).





5.1 General

The RCP-48X Control Panel is a solid state electro-mechanical device designed to give long, trouble free service with minimum maintenance requirements. If problems do occur, follow the troubleshooting procedure provided. If additional technical assistance is required, refer to the General Assistance and Service information in the front of the manual.

5.2 Preventive Maintenance

There is little need for preventive maintenance on the RCP-48X other than the normal care which should be given to any quality electronic equipment.

5.3 Test Equipment

The test equipment recommended for servicing the RCP-48X is listed below. Equivalent test equipment may be used.

EQUIPMENT	FUNCTION
Oscilloscope - 20 MHz or higher	Waveform Monitoring and Tracing
VOM - 20,000 ý per volt or higher	Voltage and Resistance Measurements

5.4 Corrective Maintenance

The following paragraphs provide information to assist the servicing technician in maintenance of the RCP-48X. The functional description (Section 4) contains board/circuit level information to help identifying specific problems.



5.4 Corrective Maintenance Continued:

Factory Repair Service

If desired, equipment or boards may be returned to the factory (transportation prepaid) for repair. Refer to the General Assistance and Service information sheet in the front of this manual.

> Pack the equipment securely and label with the correct address. Proper packaging saves money. The small amount of extra care and time it takes to cushion a part or unit properly may prevent costly damage while in transit. Make certain that the address is both legible and complete. Failure to do so often results in delay or even loss.

NOTE: Contact PESA Switching Sytems' Service Department (listed on the General Assistance and Service information sheet in the front of this manual) for a RMA# prior to shipping.

Adjustment/Alignment

The RCP-48X has no adjustments.

Troubleshooting

Troubleshooting an RCP-48X requires the routing switcher system to be used as a test fixture. The Panel does not function except as part of the system. The only troubleshooting which can be accomplished without opening the Control Panel is to check input power (from plug-in power module).

To open the Control Panel for troubleshooting, remove the front cover and disassemble the unit as far as required to gain access to the component side of the circuit boards. Place the disassembled panel on a non-conducting surface and arrange the parts so the unit can be operated. You must be able to operate the pushbuttons and observe the resulting status indicators. You must also have sufficient access to the boards to measure voltage or observe waveforms.

Procedure: Put the RCP-48X through the operating sequence described in the operation section. Refer to Section 3.



Troubleshooting Continued:

If the Panel is nonresponsive, there may be a power problem or the CPU is not operating.

- 1. Refer to the POWER DISTRIBUTION discussion in Section 4. Refer to the remote CPU schematic in Section 6 if it is necessary to make voltage checks at the chip or component level.
- 2. If power is functioning properly, the CPU is not operating. The CPU requires a clock, a power-up reset, communications from the Controller. Refer to the CPU Board functional description in Section 4.

For partial failures:

1. Pushbutton switches fail to initiate desired operation. Refer to the CPU Board functional description in Section 4.



If a source input fails to function it may be a blocked input. Check the system configuration at the controller.

- **2.** Control indicators fail to light. Refer to the LED Driver discussion in the functional description section.
- **3.** Almost any type of functional failure can be caused by a memory failure. This type of failure can easily be checked if a substitute chip is available.



