

288X576XR Technical Addendum

SERVICE AND ORDERING ASSISTANCE

PESA 103 Quality Circle Suite 210 Huntsville AL 35806 USA www.pesa.com

MAIN OFFICE Tel: 256.726.9200 Fax: 256.726.9271

SERVICE DEPARTMENT

Tel: 256.726.9222 (24/7) Toll Free: 800.323.7372 Fax: 256.726.9268 Email: service@pesa.com

Toll-free: 800-328-1008



Publication: 81-9059-0610-0, Rev. C www.PESA.com



Table Of Contents

Chapter 1	l Introduction	1
	rpose of Technical Addendum	
1.2 14	4x144 Video (Crosspoint) Matrix Card	2
1.3 Fu	nctional Description - 144x144 Digital Video Matrix Card	2
Chapter 2	2 Installation	7
	tial Installation Steps	
	oling and Rack Space Requirements	
2.3 Vi	deo I/O Connection	7
Chapter 3	Reference Data	10
-	ference Data Introduction	
	P Switch/Rotary Switch Settings for the 288X576XR System	
3.2.1	Chassis Level Codes (Strobes) Rotary Switch Settings	12
3.2.2	Chassis Power Supply and Fan Controller Backplane DIP Switch Settings	
3.2.3	Chassis Input/Output CCA Backplane DIP Switch Settings	
3.2.4	Chassis Matrix Backplane Rotary Switch Settings	12
Figure 1-1	144x144 Video Crosspoint Matrix Card LED Indicators	2
Figure 1-1	Block Diagram – 144 X 144 Digital Video Matrix Card	
Figure 1-3:	288X576XR Router Chassis (Front View – Door Open)	
Figure 1-4:	288x576XR Router Chassis (Rear View)	
Figure 2-1:	288X576XR Chassis Rack Frame Air Space Requirements	
Figure 2-2:	288x576XR Router Input/Output Connector Arrangement	9
Figure 3-1:	288x576XR Matrix Crosspoint CCA I/O Channel Assignments	
Figure 3-2:	Chassis and Level Code Switch Settings	
Figure 3-3:	288X576XR Control A Termination Jumpers, Power Supply	
Figure 3-4:	Input/Output Backplane DIP Switch Settings	
Figure 3-5:	Matrix Backplane Rotary Switch Locations	16
	List Of Tables	
Table 1-1	144x144 Video Crosspoint Matrix Card LED Descriptions	3
	Matrix Backplane Rotary Switch Settings.	

TECHNICAL ADDENDUM Cheetah Series 288X576XR P/N: 81-9059-0610-0 Rev C

October 2010

Chapter 1 Introduction

1.1 PURPOSE OF TECHNICAL ADDENDUM

This Technical Addendum (TA) introduces the 288 Input by 576 Output (288X576XR) Routing Switcher, a member of the XR family of routers built by PESA utilizing our 144X144 Matrix Circuit Card Assembly (CCA). The high I/O density of the 144X144 matrix allows larger capacity systems occupying the same rack frame space requirements as previous Cheetah Generation 1 routers. The 288X576XR router is housed in a newly designed frame occupying 18 rack units (RU).

PESA's latest high density routers are all housed in entirely new chassis frames; but just as previous generation frames, the new frames offer a great deal of versatility and flexibility due to the modular concept of the component backplanes used to configure a system. When a Cheetah Switcher is built, a chassis frame of the proper size to accommodate the required number of CCAs, Modules and other system components is fitted with backplane assemblies that interface the Input and Output CCAs (mounted through the rear of the switcher frame) with the Matrix CCAs, Power and Control components located internal to the switcher frame. Likewise, the Matrix CCAs and other internal components attach to dedicated backplanes for power and signal distribution. The various types of backplanes (I/O and Matrix) used to configure a system are interconnected. A series of DIP switches and rotary switches on the various backplanes are set to assign the "personality" to each of the system components. This scheme of assigning identification to the backplane and interface ports allows full interchangeability between like CCAs in the system.

It is assumed that the user has access to Technical Manual 81-9059-0570-0, Rev. A, entitled *Cheetah Series Video Matrix Switchers*. It is also assumed that the user has a good understanding of the structure of a routing switcher and the top-level function of the various Circuit Card Assemblies (CCAs) and other modules used in the frame. With the exception of the items addressed in this TA, the hardware and components introduced and discussed in the Technical Manual apply to the 288X576XR switcher. Refer to the Technical Manual for system control panel connections and reference data for the Input CCA, Output CCA and Power Supply Module. Use this TA for all video connector rear panel layouts, video connection data, configuration switch settings and reference data for the 144X144 Matrix CCA. For the user who may be unfamiliar with the previous generation Cheetah Series, a brief background of the previous generation product and the differences this router introduces are presented in the following paragraphs.

The key difference between any series of Cheetah routers is the Matrix CCA and its associated backplane. Cheetah Generation I CH Series switchers are built around a 64X64 Matrix CCA that provides an array of 64 inputs and 64 outputs available on each card. Later Generation I frames in the CX Series use 128 input by 128 output Matrix CCAs, offering double the crosspoint density on each card. As product technology evolved, PESA Engineers developed our latest 144 Input by 144 Output (144X144) Matrix CCA. This larger array card allows for denser array matrices using the same rack space as previous Generation I Series frames.

Contained in this TA, as a supplement to the Cheetah Generation I Technical Manual, is an introduction to the 144 Matrix CCA; plus specifications, layout drawings, DIP and rotary switch settings, and card slot identification peculiar to the 288X576XR system configuration.

1.2 144x144 VIDEO (CROSSPOINT) MATRIX CARD

As the name implies, the 144 X 144 digital matrix card accepts up to 144 SDI or HD video sources from the input buffer cards and provides up to 144 output channels to the output combiner cards. All switching is done by a special purpose device, controlled by commands from the matrix frame controller. Any input signal may be routed to any or multiple output channels of the card. When the I/O capacity of the switcher is greater than can be satisfied by a single 144 X 144 matrix card, as is the case with the 288X576XR frame addressed by this TA, multiple matrix cards are used to meet the required capacity.

There are six LEDs located on the front edge of each matrix card that provide a visual indication of the operational status of the card, these are identified by Figure 1-1. Table 1-1 lists the possible states and interpretation data for the LEDs.

Figure 1-2 is a block diagram of the 144 X 144 digital matrix card. Paragraph 1.3 presents a narrative description of the circuit functions shown on the block diagram.




FIGURE 1-1 144x144 VIDEO CROSSPOINT MATRIX CARD LED INDICATORS

1.3 FUNCTIONAL DESCRIPTION - 144x144 DIGITAL VIDEO MATRIX CARD

Refer to Figure 1-2 as we discuss the various circuit functions of this card. There are 144 identical input channel paths provided. Video signals are derived from the output channels of the input buffer cards and routed to the inputs of the matrix card. As a signal enters the card it is routed to an Input Buffer stage, internal to the crosspoint device. This device contains the switching circuitry to deliver a signal on any of its 144 input channels to any of its 144 output channels. Switching data for the crosspoint device is received from the on-board microcontroller circuitry. The crosspoint also contains 144 output buffer stages, internal to the device, for isolation. Video from each device channel is available at the card edge connector where it is routed to the output combiner cards.

October 2010



The On-Board Microcontroller is the interface between the matrix card and the frame control system. The microcontroller constantly monitors the status and health of the card and reports this data to the system frame controller. Commands from the frame controller are interpreted by the microcontroller circuitry and select the active inputs and outputs of the crosspoint device. Data indicating the status of the operating voltage rails is sent to the microcontroller by circuitry contained in the Voltage Regulator stage. The microcontroller also provides a visual indication of certain board functions by controlling the operating state of the status LEDs. Operating voltages necessary to power the matrix card circuitry are derived from on-board voltage regulator devices.

TABLE 1-1 144x144 VIDEO CROSSPOINT MATRIX CARD LED DESCRIPTIONS

LED	COLOR	STATUS	DESCRIPTION
+28V	Green	ON	Indicates that the +28V power is stable and within normal operating parameters.
		OFF	Indicates that +28V is not stable; power supplies are not working.
+2.5V	Green	ON	Indicates that the +2.5Vpower is stable and within normal operating parameters.
		OFF	Indicates that +2.5V is not stable; power supplies are not working.
+1.2V	Green	ON	Indicates that the +1.2Vpower is stable and within normal operating parameters.
		OFF	Indicates that +1.2V is not stable; power supplies are not working.
Ctrl Err	Red	ON	Indicates that a control error has occurred, or that a loss of receive clock from frame controller has been detected. A control error includes a bad CRC of the received data, incorrect number of words in the message being received, or corrupted data in the message being received. The LED will remain on until a message with a good CRC has been received.
		Blinking	Indicates a missing receive clock error.
		OFF	No alert conditions are present.
In Use	Yellow	ON	Indicates that a crosspoint on the matrix card is activated.
Fan ERR	Red	ON	Indicates a failure of the cooling fan on-board the crosspoint device






FIGURE 1-2 BLOCK DIAGRAM - 144 X 144 DIGITAL VIDEO MATRIX CARD

The Input CCAs and Output CCAs used in the 288X576XR switcher configuration are the same as the Generation I components discussed in the Cheetah Technical Manual referenced in the first paragraph of this addendum. Please refer to that manual for information on the Generation I components.

There are eight 144X144 Matrix CCAs used in the 288X576XR configuration. A very basic sketch of the chassis layout is shown in Figure 1-3. This diagram identifies the location of the System Controller CCA(s), Frame Controller CCA(s), Power Supply Modules and the Matrix CCAs. Figure 1-4 provides a rear view of the rack frame with input and output connection points located.



Power Breaker 1 Power Breaker 2 AC Rectifier 1 Fan Access AC Rectifier 2 Panel Fan Controller 1 Control A Termination 8-Position DIP Switch Jumpers Power Supply Modules (Up To 6) Fan Controller 2 Fan Controller (Power Supply Modules Shown In Phantom, To Allow View Of 8-Position DIP Switches) Switch AC Filter Assy Rotary Switches (10) For Chassis Slot Not Used (9 9 0 00 **9 9** Strobe Configuration (::::) Fuses (Blade Type) System Controller CCA < • One or Two (For Redundancy) Frame Controller CCA \llbracket One or Two (For Redundancy) 0 0 0 144X144 Matrix CCAs (8) and 288X288 Matrix Backplanes (2) S3 S4 | S6 S3 S4

FIGURE 1-3: 288X576XR ROUTER CHASSIS (FRONT VIEW – DOOR OPEN)



Quick Reference Chart Input/Output Connector Channels By I/O Card Slot Number INPUT/OUTPUT CARD SLOT NUMBER **OUTPUT CHANNELS** Output Channels <u>On Card</u> Input/Output Card Slot <u>Number</u> Output Channels <u>On Card</u> Output Channels <u>On Card</u> Input/Output Card Slot Input/Output Card Slot <u>Number</u> 50 513 - 576 51.0 Number 1 - 16 17 - 32 33 - 48 321 - 336 337 - 352 129 - 144 52 E 145 - 160 161 - 176 14 15 16 42 23 4 5 6 7 8 9 53 C 353 - 368 369 - 384 177 - 192 49 - 64 65 - 80 54 C 44 45 46 47 385 - 400 401 - 416 193 - 208 17 18 19 20 21 22 209-224 81 - 96 225 - 240 417 - 432 433 - 448 97 - 112 POWER IN 1 POWER IN 2 241 - 256 257 - 272 449 - 464 465 - 480 10 11 273 - 288 289 - 304 50 51 529 - 544 545 - 560 23 481 - 496 INPUT/OUTPUT CARD SLOT NUMBER 12 24 497 - 512 305 - 320 561 - 576 INPUT CHANNELS NOTE Input Card Slots are indicated by BOLD outlines and BOLD ITALICS text on the figure and in this chart. Input Channels <u>On Card</u> Input Channels <u>On Card</u> nput/Output Card Slot <u>Number</u> Channels On Card **OUTPUT CHANNELS: 129-512** Number <u>Number</u> 1 - 16 17 -32 31 32 97 - 112 113 - 128 193 - 208 37 38 26 209 - 224 INPUT/OUTPUT CARD SLOT NUMBER 209 - 224 225 - 240 241 - 256 257 - 272 273 - 288 27 28 33 - 48 49 - 64 33 34 129 - 144 145 - 160 39 40 29 30 65 - 80 35 36 161 - 176 177 - 192 53 54 81 - 96 **BNC Connector Numbering Detail** (•) \odot Top Connector (Lowest Channel Number) On CCA Or Option Card Channel 1, 17, 33, 49,...561 $\overline{\bullet}$ **OUTPUT 1 - 128** INPUT CHANNELS: 1 - 256 NET COM1 сом2 RCP1 RCP2 NET Alarm Alarm CONTROL INPUT/OUTPUT CONNECTORS REF1 REF2 Mon1 Mon2 Mon4 Mon4 COM4 COM3 PRC PRC Loop R CP3 NET NET AUX F.C. $\overline{\bullet}$ **Bottom Connector** \odot (Highest Channel Number) \bullet On CCA Or Option Card Channel 16, 32, 48, $\bar{oldsymbol{\odot}}_{i}$ 64,...576

FIGURE 1-4: 288x576XR ROUTER CHASSIS (REAR VIEW)

TECHNICAL ADDENDUM Cheetah Series 288X576XR P/N: 81-9059-0610-0 Rev C

October 2010

Chapter 2 Installation

2.1 INITIAL INSTALLATION STEPS

With the exception of the rear panel connector arrangement, all installation steps for the 288X576XR Switcher are the same as presented in the Cheetah Technical Manual referenced in Paragraph 1-1. Refer to the referenced Manual for initial unpacking, site preparation and installation steps.

Once the rack frame is mounted and all preliminary steps have been performed, connecting the video input and output signals and the sync reference pulse source is the next step. The rear panel arrangement of the 288X576XR Switcher is different than that called out in any configuration shown in the Technical Manual. Refer to Paragraph 2.2 of this addendum when completing the video I/O connections for proper identification of the I/O connector locations and channel numbering scheme.

2.2 COOLING AND RACK SPACE REQUIREMENTS

The 288X576XR frame must be installed in the rack frame with adequate space from all sides to insure proper cooling air flow. Figure 2-1 illustrates the minimum clearance dimensions required when the chassis is installed in the rack frame.

2.3 VIDEO I/O CONNECTION

All connections to the 288X576XR router (other than video I/O) will be the same as presented in the Cheetah Technical Manual referenced in Paragraph 1-1. Follow the installation procedure identified in the referenced manual when connecting power, sync reference and control cabling. When connecting video input and output signals follow the diagrams provided in this Technical Addendum. Figure 1-4 illustrates the entire rear panel of the router and features a quick reference guide to the input and output connector configuration. Figure 2-2 in this chapter provides a closer and more detailed view of the rear panel input and output connectors. Use these references when making video I/O connections to the 288X576XR router.






FIGURE 2-1: 288X576XR CHASSIS RACK FRAME AIR SPACE REQUIREMENTS




FIGURE 2-2: 288x576XR ROUTER INPUT/OUTPUT CONNECTOR ARRANGEMENT

TECHNICAL ADDENDUM Cheetah Series 288X576XR P/N: 81-9059-0610-0 Rev C

October 2010

Chapter 3 Reference Data

3.1 REFERENCE DATA INTRODUCTION

This section of the TA provides the user with reference data peculiar to the 288X576XR Routing Switcher. In the following paragraphs you will find information that will prove useful in the event that system maintenance or repair should ever be required. Included are a diagram (Figure 3-1) showing the input and output channel assignments of the eight matrix crosspoint CCAs, plus setting information for all DIP and rotary switches used to configure the switcher.

3.2 DIP SWITCH/ROTARY SWITCH SETTINGS FOR THE 288X576XR SYSTEM

There are numerous switches used in configuring the Cheetah Matrix Switcher for any particular input/output matrix combination. Switch settings define the operational parameters for the various CCAs and modules used in the switcher and assign the "personality" to each group of backplanes and their associated CCAs. Using the switch configuration scheme prevents any "card specific" functions, settings or jumpers and allows any input, output, or matrix CCA or power supply module to be "hot swapped" on the fly with any other card or module, of the same type. These switches are all preset at the factory and should never need any maintenance or adjustment. This information is provided as a reference so that in the event any switch setting should inadvertently be changed, it can be restored to its correct setting.

Switches are of two type: rotary or DIP. A small screwdriver can be used to make adjustments to the rotary switches. The tip of a small screwdriver or other small pointed object may be used to select the ON or OFF position of the DIP switches. Please note that the DIP switches are very small and each switch section is very delicate and can easily be damaged. Use extreme care if it is ever necessary to change the position of any section of the DIP switches.

The following paragraphs discuss the configuration switch settings listed below:

- Chassis Level Codes (Strobes) Rotary Switch Settings (Paragraph 3.2.1)
- Chassis Power Supply Backplane DIP Switch Settings (Paragraph 3.2.2)
- Chassis Input/Output Backplane DIP Switch Settings (Paragraph 3.2.3)
- Chassis Matrix Backplane Rotary Switch Settings (Paragraph 3.2.4)






FIGURE 3-1: 288x576XR MATRIX CROSSPOINT CCA I/O CHANNEL ASSIGNMENTS

TECHNICAL ADDENDUM Cheetah Series 288X576XR P/N: 81-9059-0610-0 Rev C October 2010

3.2.1 Chassis Level Codes (Strobes) Rotary Switch Settings

Chassis Level Codes (Strobes) assign operational parameters to the switcher frame. There are ten rotary switches, located just above the frame controller card(s), used to set the chassis level code and other frame operational characteristics. Proper setting positions for these ten switches are shown in Figure 3-2.

3.2.2 Chassis Power Supply and Fan Controller Backplane DIP Switch Settings

The Power Supply and Fan Controller Backplane provides slots for up to six power supply modules and two Fan Controller CCAs. There are three eight position DIP switches on the backplane, each switch assigns identity data to two power supply modules. A fourth eight position DIP switch is located between the two fan controller cards – the setting of this switch determines certain operating and monitoring parameters of the fan controller cards. Proper setting positions for each switch section in the DIP packages are shown in Figure 3-3. In this figure, the power supply modules are shown in dotted lines in order for the switch locations to be visible.

Also located between the fan controller cards are two sets of jumper pins and the jumper select connector. The location of the connector selects the termination status of the control cabling to the backplane. Figure 3-3 shows the proper jumper connector orientation for the 288X576XR Frame.

3.2.3 Chassis Input/Output CCA Backplane DIP Switch Settings


Each Input/Output CCA Backplane provides slots for up to four input or output CCAs. An eight-position DIP switch, located on the lower right-hand side of each backplane, assigns a unique identity to each backplane card. Among other functions, this switch setting allows the controller circuitry to assign the input or output channel number range to each I/O CCA – thus allowing any I/O card on the rear panel to be "hot swapped" with a card of like type. Proper setting positions for each switch section in the DIP package are shown in Figure 3-4. I/O CCAs must be removed from the backplane to gain access to the DIP switch. Figure 3-4 illustrates switch location and card slots on the backplanes with no I/O CCAs installed.

3.2.4 Chassis Matrix Backplane Rotary Switch Settings

Each Matrix CCA Backplane provides slots for up to four 144X144 matrix crosspoint CCAs. There are six rotary switches located along the bottom edge of each backplane. Settings of these switches assign a unique identity to each matrix backplane and the set of matrix CCAs installed in it. These settings allow the controller circuitry to assign the input and output channel number range to each matrix backplane and each matrix CCA. Figure 3-5 shows the location of each of the six switches on each backplane board. The matrix card image used in this figure is smaller than actual size to allow the backplane components to be shown. Setting positions for each switch are provided in Table 3-1 and listed by individual backplane boards.

Setting

Description



Switch

FIGURE 3-2: CHASSIS AND LEVEL CODE SWITCH SETTINGS






FIGURE 3-3: 288X576XR CONTROL A TERMINATION JUMPERS, POWER SUPPLY AND FAN CONTROLLER DIP SWITCH LOCATIONS AND SETTINGS (FRONT VIEW)






FIGURE 3-4: Input/Output Backplane DIP Switch Settings






FIGURE 3-5: Matrix Backplane Rotary Switch Locations



TABLE 3-1: MATRIX BACKPLANE ROTARY SWITCH SETTINGS.

MATRIX BACKPLANE 1 CARD SLOTS 1-4							
SWITCH	SETTING	I/O					
S1	0	Outputs: 1-144					
S2	0	Inputs: 1-144					
S3	1	Outputs: 145-288					
S4	0	Outputs: 1-144					
S5	1	Inputs: 145-288					
S6	1	Outputs: 145-288					

MATRIX BACKPLANE 2 CARD SLOTS 5-8							
SWITCH	SETTING*	I/O					
S1	2	Outputs: 289- 432					
S2	0	Inputs: 1- 144					
S3	3	Outputs: 433-576					
S4	2	Outputs: 289-432					
S5	1	Inputs: 145-288					
S6	3	Outputs: 433-576					

