

07 Views

vsmStudio

Manual



MFU / BME 12.05.2011

Copyright

All rights reserved. Permission to reprint or electronically reproduce any document or graphic in whole or in part for any reason is expressly prohibited, unless prior written consent is obtained from L-S-B GmbH. All entries in this document have been thoroughly checked; however no guarantee for correctness can be given.

L-S-B GmbH cannot be held responsible for any misleading or incorrect information provided throughout this manual.

L-S-B GmbH reserves the right to change specifications at any time without notice.

© L-S-B Broadcast Technologies GmbH, April 2011 Gustav-Stresemann-Str. 8 D-55411 Bingen www.l-s-b.de

Content

1	New View	4
2	Opening a View	5

Using the *Views* function, it is possible to create multiple matrices with a number of selected signals. These views have the same properties as the master matrix (see chapter 6) for a limited number of signal paths that must be defined.

🗋 🖻 📙 🦂 🗙 🖻 🛱		∖ Ľ		1	- 🐝	🔥 i	•	2		33	•	•	3	3	1	19	
Views symbol in the main menu																	

The menu in which views are set up can be accessed by clicking the symbol located in the main menu bar and shown in the screenshot above.

1 New View

By right-clicking in the Views window, a new view can be created.

Views		– – X
Config 🗱	Views	
Name		7
	New View	

Setting up a new View

Selecting *New View* will open a new window. In it, a *Name*, a *Comment* (if required), and the size of the matrix (*Inputs* and *Outputs*) are defined for the new view.

lame:						
8ME						
Comment:						
Incute:	100	-	Outputs:	100	-	
niputs.	1	-		1	-	
			Г		-	20000

View settings

2 **Opening a View**

Once a new view has been created, it can be accessed directly using the drop-down menu besides the Views symbol.



New Views in the main menu

Alternatively, it can also be accessed by double-clicking on the name in the Views list.

V N	liews		x
Con	nfig 🛛 🇱 Views 🛛		
	Name		12
讙	BME		
譿	EDIT		
謿	KDO Panels Routing		
譿	Monitoring		
譿	MV Tally		
	Views list		

As with the master matrix (see chapter 6.1 Layout View), it is possible to drag and drop the necessary signal paths from the signal path list into the layout view of the empty matrix. There, they can be arranged arbitrarily. The same functions as those used in the master matrix (see chapter 6) are available for use with those defined signal paths.



Dragging signal paths into a view