

Zoom Tracking Settings



- Setting the zoom track positions
- 1. Set the zoom at the preferred position.
- 2. Press and hold the Instant Auto Iris switch, and Press Memo SW to store the zoom position.
- 3. Repeat steps 1 and 2 to set both Telephoto and Wide ends. It is possible to set only one end.
 The last setting position(s) remain stored.
- * To cancel Zoom Tracking Functions, Press and hold the Instant Auto Iris SW with MEMO for 5 sec.

Fine Focus Mode (1)

Set Focusing Rage with your preference




Focusing Range Setting Procedure

- Turn on Focus Controller Display
- Set Focusing position(1) by the Controller
- Press EXC + AUX to set one end
- · Set Focusing position(2) by the Controller
- Press EXC + AUX to set another end
- Press EXC to release the ends set


Fine Focus Mode (1)

Set Focusing Rage with your preference




Fine Focus Mode (2)

Set Focusing Rage with Factory Settings



Fine Focus Mode (2)

Set Focusing Rage with Factory Settings




Focusing Range Setting Procedure

- Turn on Focus Controller Display
- Set Focus Position by the controller
- Press assigned SW to execute FFM2
- · Factory Default Focusing Range is set
- · Press EXC to release the ends set

Portable Lens Display Menu


Basic Mode







OFF Mode



Menu: Go to Menu

IG: Auto Iris Gain Settings

A : AUX Switch Assignment

● Trk : Zoom Tracking ON/OFF

A1 : AUX1 Switch Assignment

A2 : AUX2 Switch Assignment

(I-Tq): Iris Torque Settings

[Z.M.]: Zoom Curve Mode Settings


Assignable Functions

^(D) Fr1P	Fr1F	Fr2P
Framing Preset1	Framing Preset1	Framing Preset2
switch	switch	switch
(preset speed)	(max. speed)	(preset speed)

Fr2F	Sped	Shtl
Framing Preset2 switch (max. speed)	Speed Preset switch	Shuttle-Shot switch


NON	VTR	RET
No function	VTR switch	RET switch

Portable Lens Display Functions



y/n


User:




Introduction of the Switch Functions

- Fr1P / Fr2P (Frame Preset P):
 Move towards memorized position with memorized speed.
- Fr1F / Fr2F (Frame Preset F):
 Move towards memorized position with maximum speed.
- Sped (Speed Preset):
 Move towards Wide or Tele End with memorized speed.
- Sht1 (Shuttle Shot):
 Move towards memorized zoom position and back to the original position when SW is released, with maximum speed
- VTR/RET/NON

Focus Controller FDJ-G01 / Fine Focus Mode Function





Menu Screen in Basic Mode





Press and Left and Right







 \$\darks \rightarrow \tau \forall \fo

Torque: High Comp: ON

Torque: High


Comp: ⟨ON ⟩

*Close: OFF

Iris
Torque: High
Comp: ⟨OFF⟩

*Close: OFF

Iris Closing




Iris
Torque: High
Comp: ON

Close: (OFF)

Iris ≵ [♣]
Torque: High
Comp: ON

Close: (ON)



When 2x Extender is engaged, Iris opens up 2 F Stops to compensate Video Level

