

**1275A Series
Time / Clock Display**

**Instruction Manual
Version 5, June 2010**

www.evertz.com

**EVERTZ MICROSYSTEMS LTD.
BURLINGTON, ONTARIO, CANADA**

**Corporate Head Office
5292 John Lucas Drive
Burlington, Ontario, Canada
L7L 5Z9**

Phone: (905) 335-7570 (Factory Tech. Support)
Phone: (905) 335-3700
Fax: (905) 335-7571 (Service)
Fax: (905) 335-3573 (Sales)
Toll Free: 1-877-995-3700
Web Site: <http://www.evertz.com>
Email: sales@evertz.com

Western US Sales Office:

Email: uswestsales@evertz.com

New York Sales Office:

Email: newyorksales@evertz.com

LA Sales Office:

Email: LASales@evertz.com

U.K. Sales Office:

Email: uksales@evertz.com

Overview

The Model 1275A is a multifunction time of day display, capable of acting as a self contained, pre-settable clock, or as a slave to a master clock system.

Features:

- 1 second per week accuracy in stand-alone mode
- 12- or 24-hour mode
- Internal crystal time base or AC line time base
- Reads SMPTE/EBU or DQS-B6 (optional) time code format

Operation

As a slave display the standard version of the clock reads SMPTE/EBU Time code. The user can program time zone offsets from the incoming code.

NOTE: The version that reads DQS-B6 time code is available as a special order

As a standalone clock it can be programmed to operate in either 12- or 24-hour mode. Two front panel push buttons allow presetting and accurate synchronization to a time source when the clock is operating in standalone mode.

Setting the time in Standalone Mode

To set hours: hold the SET button down for more than 1 second.
Hold the button down until the desired value is achieved.

To set minutes: press and release the SET button.
Each press of the SET button advances one minute.

To set seconds: press and release the START button.
Each press of the START button advances one second.

Rear Panel Removal and Connections

Removing the rear panel permits:

- Connection of the **power cord**
- Connection of a **time code input**
- User selection of four different **operating modes**
- Setting of the **time zone** offset.

NOTE: THE AC VOLTAGE IS FACTORY SET

LABEL		CONNECTION
SUPPLY	GND	GROUND WIRE – GREEN
	NEUT	NEUTRAL WIRE – WHITE
	LIVE	LIVE WIRE – BLACK
TIME CODE		DQS-B6 or SMPTE/EBU INPUT
COM		COMMON GROUND

Rear Panel DIP Switch Settings

An eight-position DIP switch is used to select operating modes, and to set the time zone offset.

A label on the rear panel gives an overview of the switch functions.

NOTE: The DIP switch functions of the DQS-B6 version differ from those of the standard unit.

Standard Version DIP Switch Settings

Display Mode				Time Zone					
SWITCH NUMBER:			FUNCTION	SWITCH NUMBER:					TIMEZONE
1	2	3		4	5	6	7	8	
OFF			SLAVE MODE	OFF	OFF	OFF	OFF	OFF	0 Hour
ON			CLOCK, XTAL	ON	OFF	OFF	OFF	OFF	+1 Hour
	OFF			OFF	ON	OFF	OFF	OFF	+2 Hours
	ON			ON	ON	OFF	OFF	OFF	+3 Hours
				OFF	OFF	ON	OFF	OFF	+4 Hours
		OFF	12 HOUR MODE	ON	OFF	ON	OFF	OFF	+5 Hours
		ON	24 HOUR MODE	OFF	ON	ON	OFF	OFF	+6 Hours
				ON	ON	ON	OFF	OFF	+7 Hours
				OFF	OFF	OFF	ON	OFF	+ 8 Hours
				ON	OFF	OFF	ON	OFF	+9 Hours
				OFF	ON	OFF	ON	OFF	+10 Hours
				ON	ON	OFF	ON	OFF	+11 Hours
				OFF	OFF	ON	ON	OFF	+12 Hours
				ON	OFF	ON	ON	OFF	+13 (-11) Hours
				OFF	ON	ON	ON	OFF	+14 (-10) Hours
				ON	ON	ON	ON	OFF	+15 (-9) Hours
				OFF	OFF	OFF	OFF	ON	+16 (-8) Hours
				ON	OFF	OFF	OFF	ON	+17 (-7) Hours
				OFF	ON	OFF	OFF	ON	+18 (-6) Hours
				ON	ON	OFF	OFF	ON	+19 (-5) Hours
				OFF	OFF	ON	OFF	ON	+20 (-4) Hours
				ON	OFF	ON	OFF	ON	+21 (-3) Hours
				OFF	ON	ON	OFF	ON	+22 (-2) Hours
				ON	ON	ON	OFF	ON	+23 (-1) Hour

DQS-B6 Version DIP Switch Settings

Display Mode				Operating Mode		
SWITCH NUMBER:			FUNCTION	SWITCH NUMBER:		FUNCTION
1	2	3		4	5	
OFF	OFF	---	1 LED ON	OFF	OFF	SLAVE MODE
ON	OFF	---	3 LED's ON	OFF	ON	AC LINE TIME BASE
OFF	ON	---	ALL LED's ON	ON	ON	INTERNAL TIME BASE
---	---	OFF	12 HOUR MODE			
---	---	ON	24 HOUR MODE			

Input Code Format		
SWITCH NUMBER		FUNCTION
6	7	
OFF	OFF	DQS-B6 CODE
ON	ON	SMPTE / EBU CODE

Specifications**Electrical****Power:****1275A-110:** 115V 60Hz 15 VA**1275A-220:** 220V 50Hz 15 VA**Fuse:****1275A-110:** 150 ma, 250V Slo Blo**1275A-220:** 80 ma, 250V Slo Blo**Safety:**

TÜV listed.

Complies with EU safety directive

EMI/RFI:Complies with FCC Part 15 Class A,
EU EMC Directive**Mechanical****Dimensions:**

9.6" W x 9.6" H x 2.125" D

(244mmW x 244mmH x 54mmD)

Weight:

4.4lb

Access:

1" (25mm) diameter hole in rear panel to accommodate electrical conduit.

Code input:**Standard:**

SMPTE/EBU Time code

20 k Ω balanced/unbalanced**Optional:**

DQS-B6 or SMPTE/EBU Time code

20 k Ω balanced/unbalanced**Accuracy:**

Approximately 1 sec per week

In STAND-ALONE mode on internal X-tal oscillator.

Time Zone:

+/- 12 hours in 1 hour increments

Offset from SMPTE/EBU code input on standard version..

Evertz Microsystems Ltd.5292 John Lucas Drive,
Burlington, ON L7L 5Z9**Phone:**

905-335-3700

Fax:

905-335-3573

Email:

sales@evertz.com

Service:

905-335-7570

Email:

service@evertz.com

<http://www.evertz.com>