

## Release Notes Addendum

software release **8.1** 

071072006

FIRST PRINTING: JANUARY 2000 REVISED PRINTING: OCTOBER 2002

SERIES 7000 SIGNAL MANAGEMENT SYSTEM

### **Contacting Grass Valley Group**

Region	Voice	Fax	Address	Web Site	
North America	(800) 547-8949 Support: 530-478-4148	Sales: (530) 478-3347 Support: (530) 478-3181	Grass Valley Group P.O. Box 599000	www.grassvalleygroup.com	
Pacific Operations	+852-2585-6688 Support: 852-2585-6579	+852-2802-2996	Nevada City, CA 95959-7900 USA		
U.K., Europe, Asia, Middle East	+44 1753 218 777	+44 1753 218 757			
France	+33 1 45 29 73 00				
Germany	+49 221 1791 234	+49 221 1791 235			

Copyright © Grass Valley Group. All rights reserved.

This document may not be copied, in whole or in part, or otherwise reproduced, except as specifically permitted under U.S. copyright law, without the prior written consent of Grass Valley Group, P.O. Box 599000, Nevada City, CA 95959-7900 USA. GRASS VALLEY GROUP is a registered trademark and Grass Valley is a trademark of Grass Valley Group. All registered trademarks and trademarks are property of their respective holders. Grass Valley Group products are covered by U.S. and foreign patents, issued and pending. Product options and specifications subject to change without notice. The information in this manual is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by Grass Valley Group. Grass Valley Group assumes no responsibility or liability for any errors or inaccuracies that may appear in this publication.

#### **Grass Valley Group Web Site**

The www.grassvalleygroup.com web site offers the following:

**Online User Documentation** — Current versions of product catalogs, brochures, data sheets, ordering guides, planning guides, manuals, and release notes in .pdf format can be downloaded.

**FAQ Database** — Solutions to problems and troubleshooting efforts can be found by searching our Frequently Asked Questions (FAQ) database.

**Software Downloads** — Software updates, drivers, and patches can be downloaded.

# Release Notes Addendum

### **Known Product Issues**

Table 1. Known Issues

Area	Issue	ID
Third Party Matrices	When sending a configuration file to a Series 7000 system that contains third-party matrices, the primary third-party Node Controller (NC) might reset causing the backup NC to become primary (crosspoint information could be lost). This can occur if the third-party NC is connected directly to the Series 7000 Control frame MCPU via the Node Bus. To avoid these possible problems connect all third-party matrices to the Series 7000 Control frame using GSC (Global Serial Channel) mezzanines mounted on CIF (Communications Interface) modules.	9885
Master/Slave Switches	If the MCPU is reset or switched to its backup, Concerto's controller may also switch.	29118
Dianostic Commands	Concerto doesn't support Series 7000 diagnostic commands. NetConfig reports the software version you're running.	28653
Concerto AA/AES Slices	Concerto AES and Analog Audio (AA) slices can't be mixed in the same physical matrix. Workaround: Assign the AA and AES boards to a single slice large enough to accommodate all of their crosspoints and use signal type 8 (AES).	28933
Alarm Reporting	Standard Series 7000 alarm reporting is not supported by Concerto in this release.	29119

### **Issues Resolved in Release 8.1**

Table 2. Issues Resolved in This Release

Area	Issue	
PXD Panels	Rapid selection of DST buttons (less than one second) could cause creation of unwanted Destination Groups.	7180
Chopping	When Chopping, True Tally is turned off. Therefore, if an MCPU has shared control and it is Chopping, a Take from another system won't be reflected in MCPU status. Similarly, if a system is Chopping and a Crosspoint module is removed, MCPU status will not show a NO XPT message. When Chopping is stopped, True Tally is turned on.	7196
Configuration	Multi-New won't create Source/Destination names containing numbers higher than the numbers entered in the Limits	7226
7500NB Async Config	Inputs can now be configured for asynchronous mode.	18684
7500WB Monitor	7500WB input and output monitors work, even across frames. Monitor outputs on frame A can connect to frame B.	20625
Preset Level Buttons	Preset Level buttons (e.g. All Levels) stay selected until manually de-selected. Tally responses no longer alter them.	23711
7500NB Monitor	7500NB input/output monitors work, even across frames. Monitor outputs on frame A can connect to frame B.	23797
Concerto Monitoring	Concerto Destinations can be monitored.	27281



Grass Valley Group Headquarters P.O. Box 599000 Nevada City, CA 95959-7900 USA

