

Contacting Grass Valley

| Region | Voice | Fax | Address | Web Site |
|-------------------------|--|--|--|----------------------------|
| North America | (800) 547-8949 Support: 530-478-4148 | Sales: (530) 478-3347 Support: (530) 478-3181 | Grass Valley P.O. Box 599000 Nevada City, CA 95959-7900 USA | www.thomsongrassvalley.com |
| Pacific Operations | +852-2585-6688 Support: 852-2585-6579 | +852-2802-2996 | | |
| U.K., Asia, Middle East | +44 1753 218 777 | +44 1753 218 757 | | |
| France | +33 1 45 29 73 00 | | | |
| Germany, Europe | +49 6150 104 782 | +49 6150 104 223 | | |

Copyright © Grass Valley. All rights reserved.

Grass Valley Web Site

The <u>www.thomsongrassvalley.com</u> web site offers the following:

Online User Documentation — Current versions of product catalogs, brochures, data sheets, ordering guides, planning guides, manuals, and release notes in .pdf format can be downloaded.

FAQ Database — Solutions to problems and troubleshooting efforts can be found by searching our Frequently Asked Questions (FAQ) database.

Software Downloads — Software updates, drivers, and patches can be downloaded.

FMN 075078000

Effectivity Date: January 20, 2006

TME 2111 & 5811 Fan Replacement

Purpose

The existing fans on the TME 2111 and TME 5811 boards used on Kalypso or Zodiak switcher control panels shipped before 2006 need to be replaced because the bearings wear out and fail.

Parts List

Maglev Replacement fan (supplied):

Part Number 369005901

Required Tools

The following tools are required for installation, but are not supplied:

- Medium flat blade screwdriver
- Medium Philips cross head screwdriver
- Long nose pliers
- 3/16-inch nut driver
- # 10 and # 15 Torx Screwdriver

TME 2111 & 5811 Board Fan Replacement Procedure

The original fans to be replaced (Part Numbers 3690059-00 or 3690059-10) are mounted on these boards:


- 671492300 Kalypso Classic SST board
- 671494200 Kalypso RT Proc Interface
- 671494201
- 671494202
- 671494-04
- 610093500 Kalypso Classic/DUO/HD Local Aux Panel
- 671634601 Zodiak-25 Frame Proc
- **1.** Locate each board installed in your facility in order to replace the original fan with the new Maglev fan supplied.
- WARNING Avoid exposed circuitry Do not touch exposed connections, components or circuitry when power is present.
- **CAUTION** Use anti-static procedures Static sensitive components are present which may be damaged by electrostatic discharge. Use anti-static procedures, equipment and surfaces during servicing.
- **2.** Remove the processor or board from the frame.

3. Locate the fan on the board. (See Figure 1 and Figure 2.)

Figure 1. 2111 Board with old fan



Figure 2. 5811 Board with old fan




4. Disconnect the red and black fan power connector.




Figure 3. Old fan on 2111 Board with red and black power connector

- **5**. Remove the metal clips holding the fan to the board.
- **6.** Remove the old fan (Part # 369005900/10).
- 7. Adjust the metal clips for the fan using a pair of long nose pliers.
 - **a.** Looking at the clip from above, use the long nose pliers to bend the clip wings so that they are at a 90-degree angle to the main body of the clip as shown in Figure 4




- **b.** Now rotate the clip so that you are looking at it from the side with the locking end away from you as shown in Figure 5. Flatten the wings on the clip so that they are aligned with the main body of the clip.
- **c.** Position the long nose pliers in the middle of the wings on the clip and bend them up to a 20-degree angle as shown in Figure 5.

Figure 5. Side View — Bending the Clip with Locking End At Distant End



in middle for insertion into fan

Figure 6. Clips before and after bending







Figure 7. Clips Before adjustment (left) and After (right)

8. Insert the ends of the two clips in the two holes on the side of the fan.

Figure 8. New fan with clips ready to be inserted and bent down



- **9.** Hook the ends of the clip through the clip holes in the fan and bend the locking end of the clip down so you can secure it to the lip of the heat sink. (See Figure 9 on page 9)
- **10.** Place the new fan (Part # 721000300) over the heat sink with the airflow facing into the heat sink (label side down).

11. Secure the locking end of the clip to the heat sink lip.




Figure 9. Placing the Fan over the Heat Sink So That the Clip Connects to the Lip

12. Connect the power plug to the new fan.



Figure 10. New fan installed on heat sink with label side down, clips secure, and power connected

Note Make sure the plus (+) and minus (-) leads on the fan power plug are connected properly.

When connecting the power connector make sure the Red wire is on the left when you are looking at the fan from the side of the board as shown in Figure 10.