

## **Introduction**

RTS OMNEO is an audio over IP solution utilising Audinate's Dante technology, making it compatible with any third party Dante-capable device. OMNEO uses standard IP protocols enabling it to work on standard Ethernet devices. OMNEO supports additional features above standard the Dante such as supporting daisy chaining of devices, multi-subnet support (via an additional device called an ARNI) and direct routing.

There are certain network requirements that need to be followed.

## **Software Requirements.**

To configure OMNEO an OMNEO Suite package is provided containing the following:

- IPedit – Used for discovery of all OMI and OKI devices and to configure the channels per device.
- AZedit – Used to assign ports to the OMI, view and configure IP address settings. Can also set up a DHCP server function on the MCII-e controllers.
- Bosch DNS-SD discovery service – Used to browse and discovery all Bosch OMNEO devices on a network.
- Firmware Upload Tool – Used to update OMI and OKI devices.
  - The automatic OMNEO Suite installs the Firmware Upload Tool plus various additional plugins that are required. Installing the Firmware Upload Tool individually is not recommended due to not installing all the necessary plug-ins.

The following software is recommended:

- Audinate Dante Controller software – used to route audio between RTS OMNEO devices and third party Dante devices.

## **Network Requirements and Constraints**

- Maximum point to point latency must be guaranteed to be less than 1ms
- Currently OMNEO is limited to a single subnet with less than 128 OMNEO devices. An ARNI is required when installing more than 128 devices or using multiple subnets. This will be available at the end of 2015.

- For multi-subnet systems or large systems above 128 devices an ARNI is required to act as the DHCP server, the DNS server and the PTP server to synchronise the audio. There are two types of ARNI depending on the application.
- Daisy chains of devices must be limited to 20
- OMNEO and Dante devices use Precision Time Protocol (PTP) for clock synchronisation. PTP uses multicast packets for this information to be sent across the network. All PTP packets multicast to address 224.0.1.129.
- OMNEO requires 5.9Mb of bandwidth per port (bi-directional audio in and out). The maximum bandwidth of the system needs to be calculated and must not exceed 70% of the weakest link.
- It is recommended that OMNEO is installed on a separate VLAN
- Switches recommended to be Gigabit Ethernet, full duplex, hardware switching capabilities and must support RSTP and QOS settings.
- The following ports need to be opened on the network:  
TCP 9470 (used for discovery and registration) and UDP 5353 (used for mDNS).
- Differentiated Services (DSCP) is used for QOS. Switches must have at least 4 output queues with strict priority packet scheduling (not weighted round robin). Time critical PTP events uses DSCP value 56 and this needs to be assigned to queue 4. Audio and PTP uses DSCP value 46. Assign this to output queue 3. Assign DSCP value 8 to queue 2. VoIP QOS settings are different and should not be relied upon. If QOS is applied to all network traffic then it becomes irrelevant.
- OMNEO devices run RSTP (Rapid Spanning Tree Protocol) for fast network convergence. If RSTP is not supported on your network a non-RSTP version of firmware for the OMI is available. OMNEO devices send BPDUs, make sure the network does not block these and switches do not shut down ports for connected devices sending these.
- It is recommended that RSTP is configured on the network switches. The key values to enter are:  
  
Hello Time: 9 seconds  
  
Max Age: 22 seconds  
  
Forward Delay: 30 seconds

Small Business  
Cisco SG300-10 10-Port Gigabit Managed Switch

Getting Started  
Status and Statistics  
Administration  
Port Management  
Smartport  
VLAN Management  
Spanning Tree  
STP Status & Global Settings  
STP Interface Settings  
RSTP Interface Settings  
MSTP Properties  
VLAN to MSTP Instance  
MSTP Instance Settings  
MSTP Interface Settings  
MAC Address Tables  
Multicast  
IP Configuration  
Security  
Access Control  
Quality of Service  
SNMP

### STP Status & Global Settings

**Global Settings**

Spanning Tree State: ☒ Enable

STP Operation Mode: ☐ Classic STP ☒ Rapid STP ☐ Multiple STP

BPDU Handling: ☐ Filtering ☒ Flooding

Path Cost Default Values: ☐ Short ☒ Long

**Bridge Settings**

Priority: 16384 (Range: 0 - 61440, Default: 32768)

Hello Time: 9 sec (Range: 1 - 10, Default: 2)

Max Age: 22 sec (Range: 6 - 40, Default: 20)

Forward Delay: 30 sec (Range: 4 - 30, Default: 15)

**Designated Root**

Bridge ID: 16384-00:e1:6d:8c:a8:e4

Root Bridge ID: 16384-00:e1:6d:8c:a8:e4

Root Port: 0

Root Path Cost: 0

Topology Changes Counts: 0

Last Topology Change: 0D/0H/57M/27S

Apply Cancel

- A priority value will need to be entered. Each OMNEO device has a priority value of 61440 configured so that it never becomes a root bridge. The maximum number of 20 devices for daisy chaining devices is a limitation of RSTP. You must ensure that the maximum number of hops from the Root bridge does not exceed 21.

- Supports fixed, DHCP or link local addressing
- OMI requires two IP addresses; one for the OMI controller and one for the audio device. Both IP addresses and MAC addresses are shown in IPedit and AZedit.
- OMNEO does not support glitch-free primary and secondary connections that other Dante devices do. If redundancy is required, cabling can be wired to provide this but switches must support and be configured for RSTP.
- Standard network cable types (CAT5E, CAT6) lengths must be adhered to (i.e. less than 100m)
- OMNEO does not support Energy Efficient Ethernet (EEE) so this needs to be disabled on network switches.
- Verify the OMNEO software suite installed on any PCs are not being blocked by a firewall.

## **OMNEO Configuration**

See separate configuration document.