

Camera System Management Software

This document describes how to install the HZC-CSM10. For details on further operations, refer to the Help of Camera System Management Software.

Recommended Environment

We recommend installing this software on a PC that satisfies the following restrictions.

Operating system	Windows 7 (with Service Pack 1 installed) Professional: 32-/64-bit Ultimate: 32-/64-bit Windows 8.1 Windows 8.1 Pro: 32-/64-bit Windows 10 Windows 10 Pro: 32-/64-bit (The software cannot be installed on Windows Vista and Windows XP.)
CPU	1 GHz or faster 32-bit (x86) or 64-bit (x64) processor
Memory	2 GB or more
Hard disk	50 MB or more of free space
Display	Resolution of 1024 × 768 or higher, 32-bit color or better
Network ports	One, IPv4 for connecting
Other requirements	The following software needs to be installed. .NET Framework 3.5.1 or later (Windows 7) .NET Framework 4.5.1 or later (Windows 8.1) .NET Framework 4.5.1 or later (Windows 10)

Installation Procedure

When installing the software, administrator privileges are needed.

An install key is also required for successful installation.

Contact your Sony representative for the install key.

1 Download the following installation package and extract it.

- HZC-CSM10_****_Windows7.zip (Windows 7)
- HZC-CSM10_****_Windows8.1_Windows10.zip (Windows 8.1/Windows 10)

The file name of the installation package differs depending on the software version. ("****" differs depending on the package version.)

Extract the installation package to any folder on the PC.

2 Select the installer.

The file names of the installer are shown in the table below. ("****" differs depending on the installer version.)

Select to install one of the following four files according to the version of your operating system and the language to be used for installation.

Operating system	Language	File name
32-bit	Japanese	HZC-CSM10-x86_ja-jp-****.msi
32-bit	English	HZC-CSM10-x86_en-us-****.msi
64-bit	Japanese	HZC-CSM10-x64_ja-jp-****.msi
64-bit	English	HZC-CSM10-x64_en-us-****.msi

3 Double-click the installer.

The installer starts.

4 Complete installation, following the instructions on the screen.

The installer may be deleted, as it is not needed once installation has been completed.

5 Start the application software from the Start menu.

Click the Start button then "All Programs," "Sony Production Camera," and "Camera System Management Software."

6 Perform network setting according to your system.

For details on the settings, refer to [Help] on the Help menu.

Read This First